

XCP Pro



XCP Pro USER MANUAL

XC3-COM-BD	RS232, RS485 communication expand board
XC-2AD2PT-BD	2 channels 12 bits analog input 2 channels PT100 temperature
XC-2PT2AD1DA	2 channels 12 bits analog input 2 channels PT100 temperature



XCP Pro User Manual

Index	Page
Chapter 1 User explanation	
1-1 System requirements	4
1-2 Installation steps	4
1-3 Uninstall steps	5
Chapter 2 Basic operation	
2-1 Open and close the XCP Pro	7
2-2 Create and open the project	8
2-3 Add and delete the PLC mode	9
Chapter 3 Basic introduction to the edit environment	
3-1 Basic interface	11
3-2 Conventional Toolbar	12
3-3 PLC Toolbar	13
3-4 Ladder logic Toolbar	14
3-5 Others	15
3-6 Menu bar	
3-6-1 File	16
3-6-2 Edit	16
3-6-3 Search/Replace	17
3-6-4 View	17
3-6-5 PLC Operate	17
3-6-6 PLC Setting	18
3-6-7 Option	18
3-7 Project bar	19
3-8 Shortcut key introduction	20
Chapter 4 Simple function realization	
4-1 Online	22
4-2 Upload/download program and PLC status control	23
4-3 Set PLC initialization value, upload/download data	
4-3-1 Initial value settings	24
4-3-2 Upload/download data	25
4-4 PLC and module information enquires	
4-4-1 PLC main unit information	25
4-4-2 BD board information	25
4-4-3 Expansion module information	26
4-4-4 Scan cycle	26
4-4-5 Clock information	26
4-4-6 Error information	27
4-5 PLC initialization	27
4-6 Lock/unlock program	
4-6-1 Password settings	28
4-6-2 Lock/unlock	28
4-6-3 Default password decryption settings	29
4-7 Printing	29
Chapter 5 Program operation	
5-1 Program mode	31
5-2 Instruction sign input	
5-2-1 Instruction prompt	32
5-2-2 Input node	33
5-2-3 Input loop	34
5-2-4 Special instruction	37

5-3	Ladder chart edit	
5-3-1	<i>Horizontal line and vertical line operation</i>	40
5-3-2	<i>Node and row operation</i>	41
5-3-3	<i>Edit comment</i>	43
5-3-4	<i>Ladder chart copy and cut</i>	45
5-3-5	<i>Ladder chart instruction management</i>	46
5-4	Relevant config	
5-4-1	<i>PLC serial port settings</i>	47
5-4-2	<i>Password settings</i>	48
5-4-3	<i>BD board</i>	49
5-4-4	<i>Can-bus communication configuration</i>	50
5-4-5	<i>Power-off retentive save memory settings</i>	50
5-4-6	<i>Expansion module settings</i>	50
5-4-7	<i>I/O settings</i>	51
5-4-8	<i>Communication mode settings</i>	52
5-4-9	<i>TCP/IP settings</i>	53
5-4-10	<i>function block list</i>	54
5-5	Soft element monitor	
5-4-1	<i>Soft element comment</i>	56
5-4-2	<i>Free monitor</i>	57
5-4-3	<i>Data monitor</i>	58
5-4-4	<i>Ladder chart monitor</i>	59
5-4-5	<i>Information bar</i>	60
5-4-6	<i>Status bar</i>	61

1 User explanation

This chapter focuses on XC XCP Pro PC software installation system requirements, installation and unloading steps.

1-1. System requirements

1-2. Installation steps

1-3. Uninstall steps



1-1 System requirements

This software is suitable for running on Windows 2000, Windows NT, Windows XP and others above.



1-2 Installation steps

1, If your operation system has not installed the Framework 2.0 library before, you should run the installation process "dotnetfx.exe" first, which is in the subfolder "dotnetfx" of the installation folder;

2, Double-click to operate the installation files "setup.exe".

① Click "Next".

② Choose the software installation path, click "next step", until the "install" button appears.



1-3 Uninstall steps

- 1, Choose "Start"→ "Setting"→ "Control panel"
- 2, Double-click "Add/Delete XCP edit tool"
- 3, Pick on "XCPro3.0" in the list, press "Delete" in the lower right corner
- 4, Click [Yes] in the "Add or Remove Programs" screen
- 5, Uninstalling XCP Pro
- 6, Prompt the uninstall is successful.

2

Basic operation

2-1. Open and close XCP Pro

2-2. Create and open the project


2-3. Add and delete PLC types



2-1 Open and close XCP Pro


Open XCP Pro.

- 1, Click: Start → All programs → XCP Pro → XCPPro.exe.
- 2, When the XCP Pro has just started, the screen will display as shown below:



Note: You can also double-click the shortcut icon  on the desktop to open the program.


To close XCP Pro:

Click: File → Exit, or just click the button , and XCP Pro will close.




2-2 Create and open the project


1, how to create a new project:

(1) Click: File → New project 'Ctrl+N', or click the  icon. When clicked, the PLC model selection window will pop up.

(2) Select the PLC model in the "Select PLC Model" windows, and then click "OK", the new project is now completed. As shown below:



2, Open project:

Choose: File → Open project, or click icon , then select *. XCP type of file in the "Open PLC project file" dialog box, then click the "open".

Note: Usually, when you open an XCP project, the system backs up the original file automatically, file named *. rak for backup. When you need to use this file, change the suffix to ". XCP", then open it in XCP Pro.




2-3 Add and delete PLC types

When a new project is created, its default name is PLC1. When you need to edit a number of PLCs, you can add multi-objects to the interface.

1, Add PLC:

Method 1 : Click File → Add PLC.



Method 2 : In project column which is on the left side, right-click "PLC1"→"Add PLC", as follows:

When a PLC is added successfully, it will be named "PLC2" incremented each time by 1, and the project column in the left side will change also, as shown below:




When editing different PLCs, you only need to click the plc. Users can also modify the name, edit communication mode, change models or delete operation on the corresponding PLC.

1, Deleting models

Method 1: Right-click the PLC and, select "Delete PLC".

Method 2: First select the PLC to delete, and then to: File → Delete PLC.

After the operation, the system will hint whether or not to delete, as follows:



To confirm the deletion, click "OK", otherwise, click "Cancel."

Note: The code between different PLCs can be copied to or from each other; the code between different projects can also use the copy and paste function.

3

Basic introduction to the edit environment

This chapter focuses on the basic structure of XCP Pro software, the main function of the toolbar, the menu bar, the project bar, and shortcut keys in common use.

3-1. Basic interface

3-2. Conventional toolbar

3-3. PLC tool bar

3-4. Ladder logic

3-5. Others

3-6. Menu bar

3-7. Project bar

3-8. Shortcut key introduction



3-1 Basic interface

Title bar: Behind the ECPPro, display the open ladder program file, name and path.

Menu bar: Choose the operation to carry out in the drop-down.


Conventional Toolbar: Display the icons of basic functions, such as copy

Ladder input bar: When adding instruction symbol, select icon.

Windows switch bar: Switch windows.














PLC Toolbar : Including upload, download, run etc.

Other: The operation of ladder.















3-2 Conventional toolbar

	New	New Create a Ladder program
	Open	Open an edited (saved) file
	Save	Save the modified or newly created file
	Cut	Cut in the the specified scope
	Copy	Copy within the scope of instruction
	Paste	Paste the cut and copied contents to a designated location
	Go back	Go back to the region of previous cursor
	Go forward	Go forward to the region of next cursor
	Search	Search the statement or string
	Node	Show node comment
	Instruction tooltip	Instruction tooltip open/close
	Printer	Print the current file
	Help	See related XC instructions for use



3-3 PLC toolbar

	Download	Download the editing program or data into PLC EMS memory
	Upload	Read the program or data in PLC memory out
	Run	Run PLC
	Stop	Stop PLC
	Lock	Lock program
	Unlock	Unlock program
	Lad monitor	Monitor the operation process of ladder chart program
	Data monitor	Monitor and set state, data of all PLC soft elements
	Free monitor	Monitor and set state, data of specified PLC soft elements
	Software serial port config	Configuration of serial port for connection to PLC









3-4 Ladder logic toolbar

	Insert a node		Set
	Insert a row		Instruction frame
	Delete a Node		Horizontal Line
	Delete a Row		Delete Horizontal Line
	Normally Open Node		Vertical Line
	Normally Closed Node		Delete Vertical Line
	Rising Edge Pulse		PID Instruction Parameter Config
	Falling Edge Pulse		Pulse Instruction Parameter Config
	Output		High-speed Count 24-section Config
	Reset		G-BOX SMS Config



3-5 Others

	Auto-adapt Col Width	Auto-adjust col width to a appropriate length
	Zoom In	Zoom in ladder chart
	Zoom Out	Zoom out ladder chart
	To Ladder	Convert instruction list into ladder chart
	To Instruction List	Convert ladder chart into instruction list
	Grammar Check	Check user procedure on grammar



3-6 Menu bar


3-6-1 File

File	Edit	Search	View	
	New project	Ctrl+N		Creat a new project
	Open project			Open a created project
	Close Project			Close the current project
	Save Project	Ctrl+S		Save the current project
	Save Project As			Save the current project with a new file name
	Add PLC			Add a new PLC edit object
	Delete PLC			Delete the selected PLC edit object
	Change PLC Model			Change the selected PLC model
	Import Download File			Import/export as download file (no source file), used for production in procedure secrecy circumstance
	Export Download File			
	Print Set	Ctrl+P		Set print option
	Print			Start print
	Recent Projects			Can open recent edited project
	Exit			Exit





3-6-2 Edit

Edit	Search	View	PLC Ope	
	Undo	Ctrl+Z		Withdraw last operation(Repeat 20 times)
	Redo	Ctrl+Y		Resume last withdrew operation (Repeat 20 times)
	Cut	Ctrl+X		Cut instructions, ladder chart
	Copy	Ctrl+C		Copy instructions, ladder chart
	Paste	Ctrl+V		Paste the copied/cutted instructions/ladder chart in specified place
	Select All	Ctrl+A		Pitch on all current instructions/ladder chart
	Delete	Delete		Delete the chosen instructions, ladder chart
	Insert Row	Shift+Ins		Insert a row in specified place
	Delete Row	Shift+Del		Delete the current row
	Delete Vertical Line			Delete the current vertical line
	Insert Node	Ins		Insert a node in specified place
	Delete Node			Delete the current node
	Edit Node Comment			Comment about the node
	Lad Instruction			Ladder icons, usage see "Ladder input bar"

3-6-3 Search/replace

Search	View	PLC Operate	
	Search Reg	Ctrl+F	Search specified soft element
	Search Step	Ctrl+T	Search specified step ID
	Replace	Ctrl+R	Replace of specified content
	Go Back	Alt+Left	Go back to the region of last cursor
	Go Forward	Alt+Right	Go forward to the region of next cursor (Relative to go back operation)

3-6-4 View

View	PLC Operate	PLC Setting	
	Data Monitor Window		Show data monitor window
	Free Monitor Window		Show free monitor window
	Project Window		Show project window
	Instruction Help Window		Show instruction help window
	Message Window		Show message window
	Tool Bar		Show Toolbar
	Status Bar		Show status bar
	Zoom In		Zoom in the ladder to display
	Zoom Out		Zoom out the ladder to display
	Show Lad		Show ladder chart
	Show Instruction List		Show instruction list
	Show Node Comment		Show node comment in ladder chart
	Used Reg List		Show the used soft element list
	Node Comment List		Show the node comment list

3-6-5 PLC operate

In the basic operation of the PLC, there are several items listed below that need attention:

- The use of secret download

This protects the users' intellectual property, after the use of secret download, the program or data in PLC will never be able to upload, and the program is unable to be deciphered.

- Stop PLC when PLC reboot

In the instance of a program error, in the run mode you will not be able to communicate, set PLC to stop mode, then you can re-download the user program and set PLC to run mode.

- Lock/Unlock program

When using the function, first set the user program password, then download, password and program will download into PLC together. When the user wants to upload, they need to input the password to unlock the PLC first, and then they can upload.

When the PLC is password protected, it can be re-downloaded with a new user program,. The password is used to protect a specific user program.

Note: Specific PLC information see P29.

3-6-6 PLC setting

PLC Setting	Option	Window
PLC Serial Port Setting	_____	PLC serial port parament setting
Password Setting	_____	PLC encrypt password setting
BD Setting	_____	PLC expansion BD board specified setting
CAN Setting	_____	CANBus communication specified setting
Module Setting	_____	Expansion module basic setting
PLC Init Value Setting	_____	PLC initialization value setting
Hold Mem Setting	_____	Power-off hold mem setting
PLC Initialization	_____	Initialize PLC to factory state

3-6-7 Options

Option	Window	Help
Communication Mode Config	_____	PLC communication mode config
TBOX Device Config	_____	TBOX device config
Func Block Config	_____	Function block config
Software Serial Port Config	_____	Software serial port parament config
Default Unlock Psw Config	_____	Default unlock password config
Instruction Tooltip	_____	Open/close instruction tooltip function




3-7 Project bar

The left column includes "Project bar" .

The details in the project bar have been related to it in the menu bar and tool bar.

Instruction class bar: The instructions classified in accordance with the different functions, and then users can choose directly, as follows:





3-8 Shortcut key introduction

Ctrl+N	Create a new project	Shift+ F6	Falling edge pulse
Curl	Save project	F7	Output
Ctrl+P	Print config	Shift+ F8	Reset
Ctrl+Z	Undo	Shift+ F7	Set
Ctrl+Y	Redo	F8	Other
Ctrl+C	Copy	F11	Horizontal line
Ctrl+V	Paste	Shift+F11	Delete horizontal line
Ctrl+X	Cut	F12	Vertical line
Ctrl+A	Select all	Shift+F12	Delete vertical line
Delete	Delete	Ctrl+F	Search soft element
Shift+Insert	Insert a rung	Ctrl+T	Sear step ID
Shift+Delete	Delete a rung	Ctrl+R	Replace
Ins	Insert a node	Alt+Left	Go back
F5	Open node	Alt+Right	Go forward
F6	Close node	Ctrl+G	Grammar check
Shift+ F5	Rising edge pulse	F1	Help

4

Basic operation

This chapter focuses on the use of PLC basic functions, including online, upload/download program, run/stop PLC, upload/download data, specified information search, PLC initialization, lock/unlock program, print, etc.

4-1. Online

4-2. Upload/download program and PLC status control

4-3. Set PLC initialise value, upload/download data

4-4. PLC and module information enguires


4-5. PLC initialisation


4-6. Lock/unlock program

4-7. Print




4-1 Online


- 1, Click menu bar: Option → Software serial port config, or click the  icon.



- 2, In "Config Software Com Port" window, choose the correct serial port, baud rate, parity, or click "Check", software will check and set correct serial port, baud rate, parity automatically.
- 3, When "Connect PLC Succeeded" shows red in the left bottom of "Config Software Com Port" window, online connection is successful, click "OK", to continue other operations.






- 4, When online fails, "Communication Error" will show in red wording in the left bottom of "Config Software Comport" window, please check computer comport, communication cable and PLC communication port and repeat procedure.







4-2 Download/upload program, PLC state control


- 1, When you are successfully online, click "PLC operation" in menu bar → "upload program & data", or click the  icon, this will upload the PLC program. Click "project" in menu bar → "save project", or click the  icon, to save program.



- 2, When you are online successfully, click "PLC operate" in menu bar → Download Program & Data, or click the  icon, the program will then download into the PLC. If the PLC is running, the "stop running PLC" window will pop up.



Choose "OK", The PLC will stop running, then download your new program. While downloading, the gauge pop up will show.



After downloading program, click  button to run the PLC.

- 3, State control:

After online, click  button to run the PLC and click  button to stop the PLC.



4-3 PLC toolbar

4-3-1 Initial value settings

1. Click "Set Reg Init Value" in project bar, the "Init Reg Value" window will pop up.

Begin	End	Point	Comment

Dec Bin Hex No Sign ASCII Upload Download Default:

+0 +1 +2 +3 +4 +5 +6 +7 +8 +9

2. "Upload": Upload the data of PLC soft element.

"Download": download the set value into PLC.

The numerical value can switch between "decimal", "binary", "hexadecimal", "no symbol" and "ASCII".

3. Add soft element: Click "add" button, "Add Reg Init Value Range" in the window pop up, choose register model 'D' or 'FD', then set the start and end address.

Type

☒ D ☐ FD

Begin: 0 End: 0 Num: 0

OK Cancel

The chart below is the initial value settings of adding two registers, double-click address ID, and modify numerical value.

Begin	End	Point	Comment
D0	D10	11	
D100	D120	21	

Dec Bin Hex No Sign ASCII Upload Download Default:

+0 +1 +2 +3 +4 +5 +6 +7 +8 +9

4-3-2

Method 1: For bit address values, then use "upload", "download" button.

Method 2: For word address values, then use "PLC operate" in menu bar→"Upload data", "Download data".




4-4 Ladder logic toolbar

Method1:

- ① Click "Project column" → "PLC information", the catalogue will appear.
- ② Click "PLC main unit information", "BD board information", "expansion module information", "scan cycle", or "error information" information.

Method 2:

Click correlative items in the left side, "Project column" → "PLC information", will display information, shown on right.



4-4-1 PLC main unit information


Shows PLC series, model, slave version and subsequent master version.

4-4-2 BD board information

Shows BD input/output points, input/output bytes, primary/secondary version, and BD board name.


4-4-3 expansion module information

Shows module information (content as BD board).




4-4-4 Scan cycle

Show current cycle, Min/Max cycle of ladder chart program.




4-4-5 Clock information

Shows current clock date information.




4-4-6 Error Information

Shows compilation error information.



4-5 PLC Initialization

In the main menu bar Select: PLC setting → PLC Initialization, PLC will be initialized back to original factory settings.






4-6 Lock/unlock program



When password protection is set, the PLC program cannot be read out in locked state. If repeated entering of wrong password error occurs the PLC will block the password automatically. To reopen password entry, switch off the power to the PLC, wait a few seconds before powering back on and then re-enter password and upload.

4-6-1 Password settings

In project bar, click "PLC setting" in project bar click "Password", or "PLC config" in menu bar click "Password", now the password can be set and modified. The password is made up of 6 letters/numerals. *The system default password is six zeros, i.e. no password.*



4-6-2 Lock/unlock

When the password is successfully entered, click  icon to lock the current PLC. Or click  icon to unlock the current PLC, so the program can upload as normal.

4-6-3 The default password decryption settings

Top menu bar "Option"→ "Default Unlock Psw Config", set unlock password.



In the process of using a locked PLC frequently, or entering different passwords to different locked PLCs, the user can set a default decryption password. As shown above, the user can set a number of decryption passwords. Then during uploads there is no need to enter passwords repeatedly.



4-7 Printing

Click: File → Print, the print config window will pop up, the program can be printed in ladder chart or instruction mode.

Print object:

1. Ladder chart, command, note;
2. Print all or part (separated with cursor), all is allowed.

Print settings:

1. Choose printer
2. Print range
3. Print amount

5

Basic operation

This chapter focuses on the introduction in the XCP Pro program environment, including methods for configuration and idiographic operation process, which may be involved in a wide variety of programs.

5-1. Program mode

5-2. Instruction sign input

5-3. Ladder chart editing

5-4. Correlative configuration


5-5. Soft element monitor



5-1 Program mode

XCP Pro can program in two methods: ladder logic or statement list program.

Ladder logic programming: Is chosen by the majority of PLC programmers and maintenance personnel.




Statement list program: Is used for PLCs where maintenance personnel have no access to the PLC and ladder monitoring is not required.

```
PLC1 - PLC1-
0 LDI X10
2 CALL P0
4 LDI T0
6 OUT Y0
8 LD M8000
10 OUT T0 K100
13 LD T0
15 OUT Y1
17 LDP X13
19 ORP X14
21 SET S0
23 LDP X12
25 RST T1
27 RST T0
29 STL S0
31 LDI T1
33 OUT Y2
35 LD M8000
37 OUT T1 K50
40 RST Y1
42 LD T1
44 OUT Y3
46 STLE
47 FEND
48 P0
50 LD M8000
52 OUT Y3
54 LDP X12
56 RST Y3
58 SRET
59 LD M8000
61 PLSR D0 D2 D4 Y0
66 OUT C600 D10 D100
```




5-2 Basic interface


5-2-1 Instruction prompt

When users write instructions in ladder logic mode, they can open instruction prompt function via click "" icon. In manual input state, the system will automatically list correlative instructions for users to choose, and put up choice tips on operand.

For those not familiar with user's operation.







As shown in the left figure, when input "LD", a drop-down menu will appear starting with "LD". Convenient for users' who are not familiar with the instructions.





After the instruction is confirmed, the system will put up correlative prompt on operand, such as operand attribute and available address type, etc.

5-2-2 Input node





Icon	Function	Shortcut key
	Commonly open node	F5
	Commonly close node	F6
	Rising edge	Shift+F5
	Falling edge	Shift+F6

This example will explain the instruction input:

Mouse left click on a certain node in ladder chart, the display area within the dotted line box denotes the chosen node; first click the  icon (or press F5 key), the figure will show a dialog box (LD M0), it can edit instruction and loop in dialog box. When editin is finished, press "Enter" button.




5-2-3 Input loop


Icon	Function	Shortcut key
	Output loop, timer and counter	F7
	Set loop	Shift+F7
	Reset loop	Shift+F8
	Edit instruction	F8


Next take this example to explain the instruction input:

Ex1: Loop output


- ② After the ladder's first node X0 input, the dotted line box moves right one lattice;




- ② Click  icon (or press F7 key), the instruction dialog window pop up for (OUT);



- ③ Input Y0 in the cursor place;




- ④ Press the "Enter" key, if input is correct, then dotted line box will move to the next row; if not, the node will show in red, then double-click the node to modify.




EX2: Timer and counter input


1. The input method for timer: OUT+Timer number+blank+K timing seconds




After pressing enter, then dotted line box line will wrap.




2. Counter input mode: OUT+blank+counter number+blank+K count value




After pressing enter, the dotted line box line will wrap.




Ex3: Operand instruction input

1. Click the  icon (or press F8 key), on left side column will show instruction list; double-click the input instruction, the instruction is activated in the appointed area, input parameter.




2. Users who are familiar with instructions can double-click the input area, and manually input instructions and parameters;


Double-click the activated area:



Input instruction and operand in dialog box.



3. After input is entered, then input area line will wrap.



Notice:

Instruction input mode: instruction + blank + operand.
The red node means an error has occurred

5-2-4 Special instructions

The several instructions mentioned below, can let the user complete an instruction set through the icon dialog box and format the parameter settings at a glance.

1. PID instruction

➤ Parameter settings and instruction transfer

Put the cursor in instruction input point, then click the **PID** icon in instruction bar, the parameter set dialog box will pop up, the settings include address, PID parameter in common use, mode settings, overshoot, direction, etc. As follows:

PID Instruction Parameter Config

Target Value (SV): D0 Measure Value (FV): D10 Parameter: D4000 Output: Y0

Parameter Config

☒ Manual ☐ Auto

Sampling Time: 0 ms

Proportion Gain (KP): 0 %

Integration Time (TI): 0 *100ms

Differential Time (TD): 0 *10ms

PID Computation Scope: 0

PID Control Death Region: 0

Self Study Periodic Value: 0

Mode Config

☒ Common Mode ☐ Advanced Mode

Input Filter Constant (a): 0 %

Differential Increase (KD): 50 %

Output Upper Limit Value: 4095

Output Lower Limit Value: 0

Direction Config

☒ Negative Movement ☐ Positive Movement

Negative Movement: Along with the increase of the measures definite value FV, outputvalue MV will also reduce. It's usually used in heat up control.

Positive Movement: Along with the increase of the measures definite value FV, outputvalue MV will also increase. It's usually used in cool control.

Hold Mem Register: Can't Read
Parameter Range: D4000 ~ D4043

Read From PLC Write To PLC OK Cancel

After setting the parameter, click "OK", the instruction will appear in the ladder chart window, as follows:





➤ Parameter modification

To edit parameters, double-click the instruction to modify the addresses.

2. Pulse output instructions

➤ Parameter settings and instruction calling


Position the cursor on instruction input point, then click the  icon in instruction bar, parameter setting dialog box will pop up, then set items including instruction types, bit, segment, frequency, accelerate and decelerate time, config, address, etc. As shown below:




The dialog box is titled "Pulse Instruction Parameter Config". It contains the following fields and controls:

- Pulse Instruction:** A dropdown menu showing "Pulse Output With Accelerate And Decelerate: PLSR".
- Bit/Segment Selection:** Radio buttons for "16 bit", "32 bit", "Single", and "24 Segment". "Single" is selected.
- Frequency:** A text box containing "D0".
- Pulse Number:** A text box containing "D2".
- Accelerate And Decelerate Time:** A text box containing "D4".
- Output Pulse Y Num:** A text box containing "Y0".
- Config Value Section:**
 - Accelerate And Decelerate Time:** A numeric spinner box set to "0" with "ms" unit.
 - 1 Frequency:** A numeric spinner box set to "0".
 - 1 Pulse Num:** A numeric spinner box set to "0".
- Buttons:** "Read From PLC", "Write To PLC", "OK", and "Cancel".

When parameter settings are completed, click "OK", this will present to the ladder chart area, shown as follows:





➤ Parameter modification

Modify the parameters, by double-clicking the instructions to modify an address. You can also single-click the instruction, then click the  to modify parameter.

3, High speed counter 24-segment instruction

➤ Set parameter and call instructions.

Click the  icon in the instruction bar, parameter config box will pop up. The config items include high speed count; compare value, 24-segment config value, etc. As shown below:




The dialog box is titled "High Speed Count 24 Section Config". It contains the following fields and controls:

- High Speed Count:** A text box containing "C600".
- Compare Value:** A text box containing "D10".
- Interrupt Address:** A text box containing "D100".
- Config Value Section:**
 - Compare Value:** A numeric spinner box set to "1".
 - Section Num:** A numeric spinner box set to "1".
 - 1 Count Num:** A numeric spinner box set to "0".
- Buttons:** "Read From PLC", "Write To PLC", "OK", and "Cancel".

The instruction will appear in ladder chart appointed area, as shown below:




➤ Parameter modification

Double-click the instruction to modify the address. You can modify other parameters via the  icon.

4, The G-BOX SMS configuration

When XCP Pro is connected to the G-BOX successfully, you can set the SMS config.

- Parameter config and instructions call.

Click the  icon in the instruction bar, dialog box will pop up, the config parameter includes instruction name, COM port, phone number, first address, SMS content, as shown below:



The image shows a dialog box titled "MSG Instruction Config". It contains the following fields and controls:

- Instruction Name:** A text input field.
- COM Port:** Two radio buttons labeled "COM1" and "COM2". "COM2" is selected.
- Phone Num:** A text input field.
- First Address:** A text input field.
- MSG Content:** A large text area with a vertical scrollbar. The text "120" is visible in blue.
- DO-D10:** A label in blue text at the bottom left.
- Buttons:** "OK" and "Cancel" buttons at the bottom right.




5-3 Ladder chart editing

5-3-1 Horizontal line and vertical line operation


Icon	Functions	Shortcut key
	Insert horizontal line	F11
	Insert vertical line	F12
	Delete horizontal line	Shift+F11
	Delete vertical line	Shift+F12

Insert horizontal line and vertical line


1. Move the dotted line box to input place





2. Click (or press F11 key)





3. Move the dotted line box to upper right of the input place



Click  (or press F12 key)




Delete horizontal line and vertical line


1. Delete horizontal line: Move the dotted line box to delete place, click  (or press Shift+F11 key) .
2. Delete vertical line: Move the dotted line box to upper right of the delete place, click  (or press Shift+F12 key) .

5-3-2 Node and row operation


1. **Insert node:** move the dotted line box to input place.





2. Click  (or press Ins key), node right extension, a blank line will appear in dotted line box.




3. **Insert row:** move the dotted line box to input place.




4. Click  (or press Ins key), ladder chart down move a row, a blank row will appear in dotted line box.




- **Delete node:** move the dotted line box to input place.




Delete **Del** (or press Del key), dotted line box right move a line, a blank line appears.



- **Delete row:** move the dotted line box to input place.



Click **sDel** (or press Shift+Del key), the row of dotted line box is deleted, the next row up will move a row automatically.



5-3-3 Edit comment


In menu bar click View → show node comment, then you can display and close ladder chart node comment.

1, Add soft element comment


Move the dotted line box to comment soft element, right click, then menu will pop up.




Click "Modify Reg Comment " icon, the edit comment box will pop up;




③ Add and modify words in dialog box;



④ Click "OK", then show node comment, all the comment information will show in the bottom of the element.




- In the mode of ladder chart don't show comment, move the mouse to soft element, then an information box will emerge to show soft element comment information.





- Click "Reg Comment" in the left project bar, or click "View" in menu bar→ "Node Comment List", PLC soft element comment table pop up, you can view, modify, and add all soft elements comment in the table. The display mode can be a classified display, it can also be a whole display.


PLC1 - Ladder		PLC1- Reg Comment																			
Search:			Undo	Redo	Used	All	X	Y	M	S	T	C	D	FD	M8000	D8000	FD8000	ID	QD		
		Comment																			
MO																					
▶ M1		start																			



5-3-4 Ladder chart copy and cut


1. **Copy:** move the dotted line box to input place, press and drag the mouse, the selected area will show in hi light, click  (or press Ctrl+C);



Then move the dotted line box to paste place, click  (or press Ctrl+V)



2. **Cut:** drag mouse and select the cut area, press  (or press Ctrl+X), then move the dotted line box to paste place, click  (or press Ctrl+V).



Note: You can press Ctrl to select multi-node for cutting or pasting.

5-3-5 Ladder chart instruction management

1, The fold and unfold of program.


When user procedure is too long, effective instruction management can help with clear area management.

After being folded, the program is much more concise, to help users better grasp of the overall program situation.


2. GROUP/GROUPE

"GROUP/GROUPE" will help to organize sentence into groups, fold/expand are also suitable.

"GROUP" and "GROUPE" instructions don't have practical significance, only to organise the program into labelled sections. Usually, a GROUP will start with "GROUP", and ends with "GROUPE", the middle part is the effective user program. The following is an example of GROUP.



At the same time, it is convenient for management, All items are noted in "ladder", double-click to expand.






5-4 Conventional toolbar


5-4-1 Relevant configuration

- 1, In the project bar click PLC config → serial port, serial port set box will pop up.
- 2, Click "serial port 1", "serial port 2", "serial port 3" to set different serial ports.
- 3, There are two optional communication modes, "Modbus" and "Free protocol".
- 4, Click "Read From PLC" to get PLC default parameter.
- 5, Click "Write Into PLC" to write current parameters into the PLC, then PLC re-power.

Modbus
communication




Free protocol
communication



5-4-2 Password settings

In project bar click PLC Config → Password The password set box will pop up for password setting and modification, work together with lock/unlock functions.




5-4-3 BD board settings


In the project bar click PLC Config → BD. The BD set box will pop up.

- In "BD Config", you can choose "No config", "BD serial port", or "Other BD board".
- Click "Read from PLC" to get default BD config parameter.
- After modifying with BD board parameter, click "Write to PLC" to write set value into PLC.
-

EX: take "2AD2PT-P" type BD config as example, first pick "other BD" in "BD Config", then choose relevant BD board type in the dialog box.



Click the box before "BD-2AD2PT-P", then "BD-2AD2PT-P config" box will appear in the right. Click drop-down menu to modify its configuration, then click "Write To PLC".



5-4-4 Can-bus communication configuration

Click "PLC config" in project bar→"CAN", CAN config settings dialog box will pop up.


- Add: first select the configure item, then click "add" button to add address;
- Delete: select "configured", click "delete" button.

Note: the add and delete of item can also first select operation item, right-click, choose operation in the pop-up menu.

5-4-5 Power-off, rententive save memory settings

In project bar click PLC Setting → Hold Mem Setting. The save hold memory set box will pop up.

The value shown in the right box of each soft element, is the power-off retentive area original address. The "Input Value Range" in the lower left side, show the soft elements effective range.



5-4-6 Expansion module settings

Click PLC config → expansion module. The expansion module setting box will pop up.


Click "Read From PLC" to get default configure parameters of expansion module.

After you have chosen the settings of expansion module parameters, click "Write To PLC" to write set values into PLC.

5-4-7 I/O settings

In project bar click "PLC config" → I/O settings. The I/O setting box pop up.


I/O point mapping: refer to the relevant actual input, output definition of internal soft element number. Such as, set value to be 0 in X0,X1 position, then when input terminal is ON, soft element X0,X1 all set ON; if the set value in Y0,Y1 position all are 0, then only while soft element Y1 is ON, output terminal Y0 has export.




In Port:0
In Port:1
In Port:2
In Port:3
In Port:4
In Port:5
In Port:6
In Port:7

Click E31, pop up drop-down options, as left shown

In port property: when it's "+", the input and output state is positive logic; when it's "-", the input and output state will be negative logic.




5-4-8 Communication mode settings




Communication mode settings is usually used to set communication mode of computer and connection device(include main unit PLC, net module).

The default communication mode is serial port, when click "+", it will open TCP/IP device(via .TCP/IP settings) window, as shown below:




Click "Add GBOX" button, users can add communication device here, window will pop up as follows:




Set relevant parameters in the window, create parameter set, please refer to <<Wireless data transmission module G-BOX user manual>>, not repeated here.

The communication mode setting interface has changed, item UDP is activated, network type is activated also. Usually G-BOX use internal network type, while T-BOX uses external network type, as shown below:



Communication mode settings can also be done via clicking PLC name in project bar, right click, select "Edit PLC Communication Mode" in pop-up menu, as shown below:



5-4-9 TCP/IP settings

Set window is the same as "TCP/IP device", it can only activate UDP communication after TCP/IP device configured

5-4-10 Function block list


The window is use to show used C language function block and relevant information.

[illegible]


Function block directly compiles in software, it will save as export after completion, and can be directly transferred in ladder chart, shown as below:

The screenshot shows the 'Func Block Info Edit' dialog box. The 'Func Block Name' is 'FUN1' and the 'Version' is '1.0.0'. The 'Description' field is empty. The 'Author' field is empty and the 'Date' is '2008 6 16'. The 'OK' and 'Cancel' buttons are at the bottom right. An arrow points from the 'Add New Func Block' option in the 'Project' tree to the 'Description' field.

After confirming the input function block basic information, you will find a "FUN1" added in the project bar, as shown below:



Click "FUN1", the following interface will appear in the main window, users can edit the program here.







5-5 Soft element monitor

5-5-1 soft element comment

Click "Reg comment" in project bar, soft element comments window will pop up, you can see all or part of the soft element comment, double-click comment bar will edit the comment.




Click "used" in the window, the used soft element window will pop up, and the used element number will be listed respectively.




5-5-2 Free monitor

Click "free monitor" in project bar, the free monitor window will pop up.



Reg	Monitor value	Word length	Num Format	Comment
M10		Bit	-	

Click "Add", "monitor node input" window will pop up: input the monitor soft element capital address in "Monitor Reg" bar, set the continuous monitoring soft elements number in "Num", select soft element monitor method in "Monitor Mode" bar, select soft element show mode in "Show Mode" bar.



Monitor Reg: M10 Num: 1

Monitor Mode:


- ☒ bit
- ☐ Float
- ☐ Word
- ☐ DWord

Show Mode:

- ☒ Dec
- ☐ Unsigned
- ☐ Bin
- ☐ ASCII
- ☐ Hex

OK Cancel


After adding the, serial number, value, word length, number format and comment of relevant element list in monitor window, double-click edit its attribute.



Reg	Monitor value	Word length	Num Format	Comment
M10	OFF	Bit	-	
FD8220	1	Word	Dec	


5-5-3 Data monitor

Click "data monitor" in the project bar, the data monitor window will pop up. Data monitoring loop state or data register value in the list or the register value can also be modified and the loop state directly.



	+0	+1	+2	+3	+4	+5	+6	+7
► X0	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF
X10	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF
X20	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF
X30	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF


1. Mouse double-click loop, then state negation; double-click register, then activate value modification, press enter to confirm input.
2. Input relevant soft element number in search bar, press enter, monitor table will automatically jump to relevant place.
3. When loop state is OFF, it's blue-background black word; when is ON, it's green-background white word, shown as below:




	+0	+1	+2	+3	+4	+5	+6	+7
► Y0	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF
Y10	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF


5-5-4 Ladder chart monitor

When the PLC connection is successful and in the run state, it is especially useful for program debugging.

Click  icon in toolbar, open ladder chart monitor, soft element states of program are shown, loop in green-background white-word is ON state, real-time data in timer, register shows also in ladder chart, shown as follows:




For convenient debugging, users can right-click soft elements, change the current state, and monitor the revised operating results.



5-5-5 Information bar


Information bar contains "Error information" and "Output".

Error information: for showing syntax and run error, generally speaking, when users edit ladder chart, if sentence error, press enter, it will show in red, and show error in error information list. Shown as follows:




	Description	Project	Row	Col
✖ 1	Device's No. beyonds its spec, list bound	PLC1 - Ladder	9	11

If only checking one sentence, you can click "PLC operate"→"Grammar check". Double-click error information, then cursor will position to error place automatically, shown as below:



Output: Usually when PLC run is in error, relevant information written into output bar, prompt the operation error. As shown below:



The display of information, data monitor and free monitor can switch via as shown below:




5-5-6 Status bar

The status bar not only shows the relevant information of the current enabled PLC, but users can double-click the status display information, to quickly open the modify attributes window.

Documentation Reference				
Document Number				Revision Date
MANU	L010	R1	V1	01/09/2009
XINJE IS A REGISTERED TRADEMARK OF XINJE ELECTRICAL CO.LTD. REPLICATION OF THE INFORMATION CONTAINED WITHIN THIS DOCUMENT WITHOUT PRIOR NOTIFICATION AND AGREEMENT IS PROHIBITED.				

Documentation Reference				
Document Number				Revision Date
MANU	L010	R2	V1	05/07/2011
<p>XINJE IS A REGISTERED TRADEMARK OF XINJE ELECTRICAL CO.LTD. REPLICATION OF THE INFORMATION CONTAINED WITHIN THIS DOCUMENT WITHOUT PRIOR NOTIFICATION AND AGREEMENT IS PROHIBITED.</p>				

Engineered and supplied by:



International partners with:



Web: www.listo-ltd.com
www.xinje-support-centre-listo.com

E-mail: support@listo-ltd.com



Please consider the environment before printing this document