

MULTIFUNCTION POWER MONITOR

SMART X835

USER MANUAL



1 Introduction

The multifunction panel meter SMART X835 series is a top new-generation intelligent panel meter, used not only in the electricity transmission and power distribution system but also in the power consumption measurement and analysis in high voltage intelligent power grid.

This document provides operating, maintenance and installation instructions for the Eastron SMART X835 series. The unit measures and displays the characteristics of single phase two wires, three phase three wires and three phase four wires supplies, including voltage, frequency, current, power and active and reactive energy, imported or exported, Harmonic, Power factor, Max. Demand etc. Energy is measured in terms of kWh, kVArh. Maximum demand current can be measured over preset periods of up to 60minutes. In order to measure energy, the unit requires voltage and current inputs in addition to the supply required to power the product. The requisite current input(s) are obtained via current transformers (CT).

The SMART X835 can be configured to work with a wide range of CTs, giving the unit a wide range of operation. Built-in interfaces provide pulse and RS485 Modbus RTU outputs. Configuration is password protected.

1.1 Measurement and display parameters

- Line voltage and THD% (total harmonic distortion) of all phases
- Key factor and Crest factor
- Line Frequency
- Currents, Current demands and current THD% of all phases
- Power, maximum power demand and power factor
- Active energy imported and exported
- Reactive energy imported and exported
- Real time date and time

1.2 Pass-word protected set-up

- RS485 Modbus setting
- CT Ratio and secondary current
- PT Ratio and secondary voltage
- Pulse output setting
- Demand Interval time
- Supply system selection 1phase2wire, 3phase 3wires and 3phase 4wires
- Energy and demand information reset
- Changing Password setting
- Auto scroll display interval setting
- Wiring correction configuration
- Date and time setting
- Multi-tariff setting (optional)
- 2~60th Current and Voltage harmonic
- AO setting (only for SMART X835-AO)



TPTECH

594/22 Hatairat Rd. Bangchan Klongsamwa Bangkok Thailand .10510

www.tpotech.co.th

1.3 Current Transformer Current ratio

The unit can be configured to operate with CT ratio between primary and secondary current is 1 and 2000. There are two options of secondary current input: 1A or 5A

1.4 RS485 Serial – Modbus RTU



This uses an RS485 serial port with Modbus RTU protocol to provide a means of remotely monitoring and controlling the SMART X835 series.

Set-up screens are provided for setting up the RS485 port. See section 4.8

1.5 Pulse output

This provides 2 pulse outputs those clocks up measured active and reactive energy. The constant for both output are configurable.

2. Start-up Screens

	The first screen lights all display segments and can be used as a display check
	The second screen indicates the firmware installed in the unit and its build number.



Inst
TEST
PASS

Next the unit performs a self-test and indicates if the test passes.

3. Measurements

The buttons operate as follows



Selects the Voltage and Current display screens
In Set-up Mode, this is the “Left” or “Back” button.



Select the Frequency and Power factor screens
In Set-up Mode, this is the “Up” button



Select the Power screens
In Set-up Mode, this is the “Down” button



Select the Energy display screens
In Set-up mode, this is the “Enter” or “Right” button

3.1 Voltage and Current



Each successive pressing of the button selects a new range:

U^a 220.3 V
U^b 0000
U^c 0000
Total 00000000 Kwh






Phase to neutral voltages



TPTECH

594/22 Hatairat Rd. Bangchan Klongsamwa Bangkok Thailand .10510




www.tpotech.co.th

	Current on each phase
	Phase to neutral voltage THD%
	Current THD% for each phase
<div data-bbox="36 1110 383 1397">  </div>	
	Key Factor



3.2 Frequency and Power Factor and Demand

Each successive pressing of the  button selects a new range:

	Total kW Frequency Power factor (total)
	Power factor of each phase
	Max. Power demand



 <p>The display shows three rows of four-digit numbers for phases A, B, and C, each preceded by a small 'A' icon. Below these is a row of eight-digit numbers preceded by a 'Total' label. The unit 'A' is indicated on the right side of the phase readings.</p>	Max. Current demand
---	---------------------

3.3Power

Each successive pressing of the  button select a new range:

 <p>The display shows three rows of four-digit numbers for phases A, B, and C, each preceded by a small 'P' icon. Below these is a row of eight-digit numbers preceded by a 'Total' label. The unit 'KW' is indicated on the right side of the phase readings.</p>	Instantaneous active power (kW)
 <p>The display shows three rows of four-digit numbers for phases A, B, and C, each preceded by a small 'Q' icon. Below these is a row of eight-digit numbers preceded by a 'Total' label. The unit 'Kvar' is indicated on the right side of the phase readings.</p>	Instantaneous reactive power (kVAr)
 <p>The display shows three rows of four-digit numbers for phases A, B, and C, each preceded by a small 'S' icon. Below these is a row of eight-digit numbers preceded by a 'Total' label. The unit 'KVA' is indicated on the right side of the phase readings.</p>	Instantaneous Volt-amps (KVA)



TPTECH

594/22 Hatairat Rd. Bangchan Klongsamwa Bangkok Thailand .10510

www.tptech.co.th




<div> <div>0000</div> <div>0000</div> <div>0000</div> <div>00000000</div> </div> <div> <div>KW</div> <div>Kvar</div> <div>KVA</div> <div>Kwh</div> </div>	Total kW, kVArh, kVA
---	----------------------

3.4 Energy Measurements

Each successive pressing of the  button selects a new range:

<div>Total</div> <div>00000000</div> <div>Kwh</div>	Total active energy in kWh
<div>Total</div> <div>00000000</div> <div>Kvarh</div>	Total reactive energy in kVAh
<div>Imp</div> <div>00000000</div> <div>Kwh</div>	Imported active energy in kWh
<div>Exp</div> <div>00000000</div> <div>Kwh</div>	Exported active energy in kWh
<div>Imp</div> <div>00000000</div> <div>Kvarh</div>	Imported reactive energy in kVArh
<div>Exp</div> <div>00000000</div> <div>Kvarh</div>	Exported reactive energy in kVArh
<div>1 Imp</div> <div>00000000</div> <div>Kwh</div>	T1 Import Energy
<div>2 Imp</div> <div>00000000</div> <div>Kwh</div>	T2 Import Energy
<div>3 Imp</div> <div>00000000</div> <div>Kwh</div>	T3 Import Energy



	T4 Import Energy
	Date
	Time

4. Set-up

Long press button  to enter the set-up interface

PASS

0000

The default pass-word is 1000,if the input is wrong,the LCD displays "PASS Err"

PASS

Err




Press the button  to exit set-up interface.

4.1 Set-up Mode

4.1.1 Modbus Address

	<p>The default address is 001. press  to activate the modification.</p>
---	--


SEt
Addr
101

use  and  buttons to set the address with the range 001~247, and pressing the button  for confirmation.

Press button  to exit the number setting routine and return to the Set-up menu.



4.1.2 Baud Rate

SEt
bAud
9600

From the Set-up menu, use  and  buttons to select the Baud Rate option.
The default is 9600bps.



Press  to enter the selection routine. The Baud Rate setting will flash

Use  and  buttons to choose Baud rate 2.4k, 4.8k, 9.6k, 19.2k, 38.4k

On Completion of the entry procedure, press  to confirm the setting and press  to return to the main set up menu.

4.1.3 Parity

SEt
PAR-
NONE

From the Set-up menu, use  and  buttons to select the Parity option.



Press  to enter the selection routine. The current setting will flash.





TPTECH

594/22 Hatairat Rd. Bangchan Klongsamwa Bangkok Thailand .10510

www.tpotech.co.th

Use  and  buttons to choose Parity (EVEN / ODD / NONE)

On Completion of the entry procedure, press  to confirm the setting and press  to return to the main set up menu.

4.1.4 Stop bits

SET
STOP
1

From the Set-up menu, use  and  buttons to select the Stop Bit option.

Press  to enter the selection routine. The current setting will flash.

Use  and  buttons to choose Stop Bit (2 or 1)

On Completion of the entry procedure, press  to confirm the setting and press  to return to the main set up menu.

4.2 CT

SET
CT2
5

From the Set-up menu, use  and  buttons to select the CT option. The screen will show the current CT primary current value.

Secondary CT setting Press  to enter the CT secondary current selection routine. 5A/1A



TPTECH

594/22 Hatairat Rd. Bangchan Klongsamwa Bangkok Thailand .10510

www.tpotech.co.th

CT
RATE
0001

Set CT Ratio Value Press   to enter the CT Ratio
The range is from 0001~2000.

For example: if set the ratio to be 100, that means the primary current is secondary current x100.

4.3 PT

SET
PT2
400

From the Set-up menu, use  and  buttons to select the PT option. The screen will show the voltage PT primary voltage value.

SET
PT2
400

Secondary PT setting
Max. PT2 value is 500V

PT
RATE
0001

Set PT Ratio Value
Press   to enter the PT Ratio
The range is from 0001~2000.

For example: if set the ratio to be 100, that means the primary current is secondary current x100.

4.4 Pulse output

This option allows you to configure the pulse output. The output can be set to provide a pulse for a defined amount of energy active or reactive.

Use this section to set up the relay pulse output

Unit: kWh kWh



TPTECH

594/22 Hatairat Rd. Bangchan Klongsamwa Bangkok Thailand .10510

www.tpotech.co.th

SEt
rLY

From the Set-up menu, use  and  buttons to select the Pulse output option.



kWh

Press  to enter the selection routine. The unit symbol will flash

SEt
rLY

Use  and  buttons to choose kWh or kVArh.

kVArh

On completion of the entry procedure, press  to confirm the setting and press  to return to the main set up menu.

4.4.1 Pulse constant

Use this to set the energy represented by each pulse. Rate can be set to 1 pulse per 0.001kWh/0.01kWh/0.1kWh/1kWh/10kWh/100kWh.

SEt
rAtE
0.00 1

(It shows 1 pulse = 0.001kWh/kVArh)

SEt
rAtE
0.00 1

From the Set-up menu, use  and  buttons to select the Pulse Rate option.



TPTECH

594/22 Hatairat Rd. Bangchan Klongsamwa Bangkok Thailand .10510



www.tpotech.co.th

SET
RATE
10

Press  to enter the selection routine. The current setting will flash

Use  and  buttons to choose pulse rate.

1 pulse = 0.001/0.01/0.1/1/10/100kWh/kVArh
0.001/0.01/0.1/1/10/100 kWh/kVArh per pulse

On completion of the entry procedure, press  to confirm the setting and press  to return to the main set up menu.

4.4.2 Pulse Duration



SET
PULS
200

(The default set-up is 200ms)

SET
PULS
200

From the Set-up menu, use  and  buttons to select the Pulse width option.

Press  to enter the selection routine. The current setting will flash.

Use  and  buttons to choose pulse width(200/100/60ms)

On Completion of the entry procedure, press  to confirm the setting and press  to return to the main set up menu.










TPTECH

594/22 Hatairat Rd. Bangchan Klongsamwa Bangkok Thailand .10510








www.tpotech.co.th

This sets the period in minutes over which the current and power readings are integrated for maximum demand measurement. The options are: off, 5, 10,15 ,30,60 minutes

	<p>From the set-up menu, use  and  buttons to select the dIT option. The screen will show the currently selected integration time.</p>
<p>Press  to enter the selection routine. The current time interval will flash</p>	
<p>Use  and  buttons to select the time required.</p>	
<p>Press  to confirm the selection.</p>	

4.6 Supply System

Use this section to set the type of power supply being monitored.

	<p>From the Set-up menu, use  and  buttons to select the System option. The screen will show the currently selected power supply</p>
<p>Press  to enter the selection routine. The current selection will flash</p>	
<p>Use  and  buttons to select the required system option: 3P4W,3P3W or 1P2W</p>	
<p>Press  to confirm the selection.</p>	



4.7 CLR

4.7.1 Clear kWh

	From the Set-up menu, use and buttons to select the reset option.
Press	to enter the selection routine. The yes will flash.
Press	to confirm the setting and press to return to the main set up menu.

4.7.2 Clear KVArh

	From the Set-up menu, use and buttons to select the reset option.
Press	to enter the selection routine. The yes will flash.
Press	to confirm the setting and press to return to the main set up menu.

4.7.3 Clear Max Demand

	From the Set-up menu, use and buttons to select the reset option.
Press	to enter the selection routine. The YES will flash.
Press	to confirm the setting and press to return to the main set up menu.



4.8 Change Password

	Use the and to choose the change password option
	Press the to enter the change password routine. The new password screen will appear with the first digit flashing. Enter the new password and press to confirm.
Press to exit the number setting routine and return to the Set-up menu.	

4.9 Auto display in turns

	From the set-up menu, use and buttons to select page "SET AUTO" Press the button to activate the modification on the time. The left picture shows 2000mS, which means 2 seconds.
Use the and to set the auto display interval time.	
Press to exit the number setting routine and return to the Set-up menu.	

4.10 Reverse connected current inputs correction setting.





	<p>From the Set-up menu, use  and  buttons to select page "SET SYS CONT"</p>
	<p>Press to  enter Phase A , the default is FRD (forward)</p>
	<p>Use  and  buttons to Phase B or C setting pages</p>
<p>Press button  to confirm the setting and press  to return to the main set up menu.</p>	

4.10.1 How to operate if phase A is reversely connected

	<p>Go to phase A setting page</p>
---	-----------------------------------

SEt
IA
Frd

Press  to enter the selection routine. The FRD will flash.

Use  button to change FRD to REV.


On completion of the entry procedure, press  to confirm the setting and press  to return to the main set up menu.

4.11 How to set date and time




SEt
DAY
TE

From the Set-up menu, use  and  buttons to select page "SET DAY TE"


SEt
DAY

Press button  to enter set-up interface, you will see the date information. The format is YYYY-MM-DD




20 130828

To change it , you need press the button  to activate the modification. You will see the digits flash. Use  and  buttons to choose the correct date information.

SEt
DAY

Press button  to enter set-up interface , you will see the time information. The format is HH-MM-SS

095256

To change it , you need press the button  to activate the modification. You will see the digits flash. Use  and  buttons to choose the correct time information













Press button  to return to the main set up menu.

4.12 How to set Multi-tariffs





The meter can be set with max. 8 time periods and 4 tariffs. The user need set the starting time of each






period and choose which tariff it belongs to.

	<p>From the Set-up menu, use  and  buttons to select page "SET TE FEE"</p>
	<p>Press button  to enter set-up interface , you will see the Period 1 start time information. The format is HH-MM The left side picture show period 1 start from 00:00</p> <p>If you need change the time, please press the button  to activate the modification.</p>
	<p>After set the period 1 start time, you will see a page showing which tariff does period 1 belongs to. The left picture shows period 1 belong to FEE0.</p> <p>FEE0 means: no tariff. press  to activate the modification. use  and  buttons to choose the correct tariff from 1 to 4.</p>
<p>Press  to confirm the setting and press  to return to the main set up menu.</p>	

4.13 Harmonic checking

	<p>From the Set-up menu, use  and  buttons to select page "DISP ADU"</p> <p>Press the button , you will see the Voltage Harmonic</p>
---	---

	Press the button  , you will see the individual Voltage Harmonic from 2 nd to 60th
	U-----voltage P0 --- phase A /L1. P1 --- Phase B/L2 和 P2--- Phase C/L3 02 --- 2 nd THD %
	Press the button  , you will see the individual Current Harmonic from 2 nd to 60th
	I--- Current P0 --- phase A /L1. P1 --- Phase B/L2 ,P2--- Phase C/L3 02 --- 2 ND THD %
press  to return to the main set up menu.	

5 Specifications

5.1 Measured Parameters

The unit can monitor and display the following parameters of a single phase, 3-phase 3-wire or 3-phase 4-wire supply.

5.1.1 Voltage and Current

- Phase to neutral voltages 100 to 289V a.c. (not for 3p3w supplies)

- Voltages between phases 173 to 500V a.c. (3p supplies only)
- Percentage total voltage harmonic distortion (THD%) for each phase to N
- percentage current harmonic distortion for each phase
- Current on each phase
- Key factor
- Crest factor

5.1.2 Power factor and Frequency and Max. Demand

- Frequency in Hz
- Instantaneous power:
- Power 0 to999MW
- Reactive Power 0 to 999MVA
- Volt-amps 0 to 999 MVA
- Maximum demanded power since last Demand reset Power factor
- Maximum demand current, since the last Demand reset (three phase supplies only)

5.1.3 Energy Measurements

- Imported active energy 0 to 9999999.9 kWh
- Exported active energy 0 to 9999999.9 kWh
- Imported reactive energy 0 to 9999999.9 kVArh
- Exported reactive energy 0 to 9999999.9 kVArh
- Total active energy 0 to 9999999.9 kWh
- Total reactive energy 0 to 9999999.9 kVArh

5.2 Accuracy

- Voltage 0 • 5% of range maximum
- Current 0 • 5% of nominal
- Frequency 0 • 2% of mid-frequency
- Power factor 1% of unity (0.01)
- Active power (W) ± 1% of range maximum
- Reactive power (VAr) ± 2% of range maximum
- Apparent power (VA) ± 1% of range maximum
- Active energy (Wh) Class 1 IEC 62053-21
- Reactive energy (VARh) ± 2% of range maximum

5.3 Auxiliary Supply

Two-way fixed connector with 2.5mm2 stranded wire capacity.
85 to 275V a.c. 50/60Hz ±10% or 120V to 380V d.c. ±20%. Consumption < 2W.

5.4 Interfaces for External Monitoring

The SMART X835 provides 3 communication ports:
1 RS485 port

2 ports of pulse input

5.4.1 Pulse Output

0.001=1Wh/VArh

0.01 = 10 Wh/VArh

0.1 = 100 Wh/VArh

1 = 1 kWh/kVArh

10 = 10 kWh/kVArh

100 = 100 kWh/kVArh

Pulse width 200/100/60 ms.

5.4.2 Modbus RTU

Baud rate 2400,4800,9600,19200,38400

Parity none/odd/even


Stop bits 1 or 2

Network address *nnn* –001 to 247

5.5 Environment

- Operating temperature -25° C to +55° C*
- Storage temperature -40° C to +70° C*
- Relative humidity 0 to 90%, non-condensing
- Altitude Up to 3000m
- Vibration 10Hz to 50Hz, IEC 60068-2-6, 2g

6. Dimensions




TPTECH


594/22 Hatairat Rd. Bangchan Klongsamwa Bangkok Thailand .10510

www.tpotech.co.th

7. Wiring diagram



(Smart X835 Basic)



(Smart X835-AO)

